


phil&teds bebe / bebe hs Instruction Set



GROUP 0+
SUITABLE FROM BIRTH - 9 MONTHS APPROXIMATELY
0 to 13kg (Birth to 29lbs)

bebe / bebe hs instructions

Installing your new phil&teds car seat capsule is effortless, just follow these simple instructions and in 5 minutes you'll be off.



safe & sound

We've attained ECER44/04 safety standard

Instructions for fitting & use

Notice

1. This is a "Universal" child restraint; it is approved to ECE Regulation No. 44.04 for general use in vehicles and will fit most, but not all, vehicle seats.
2. A correct fit is likely if the vehicle manufacturer has declared in the vehicle handbook that the vehicle is capable of accepting a "Universal" child restraint for this group.
3. This child restraint has been classified as "Universal" under more stringent conditions than those which applied to earlier designs which do not carry this notice.
4. If in doubt, consult either the child restraint manufacturer or the retailer.

Only suitable if the vehicle is fitted with 3-point static, 3-point retractor safety belts, approved to UN/ECE Regulation No. 16 or other equivalent standards.

EXTREME HAZARD

Do not use in passenger seats equipped with airbags (SRS)

THESE INSTRUCTIONS ARE IMPORTANT. PLEASE READ CAREFULLY AND RETAIN FOR FUTURE USE.


The correct use and maintenance of your car seat will ensure it gives long and trouble free use. When somebody else is using your car seat, ensure they also know how to use it, especially the correct way to adjust it. The safety of your child is your responsibility.

Warnings!

1. **PLEASE READ THOROUGHLY BEFORE COMMENCING INSTALLATION, AS AN INCORRECT INSTALLATION COULD BE DANGEROUS.**
2. **PARENTS SHOULD NOT UNDER ANY CIRCUMSTANCES USE THIS CHILD RESTRAINT ON A PASSENGER SEAT EQUIPPED WITH AN AIRBAG.**
3. The child seat must only be installed in the rearward facing position.
4. Never use the child seat without fastening the child's harness correctly, and never attempt to use it without fastening it into the car as described in these instructions.
5. It is most important that the seat belt is correctly routed and the child seat tightened down on the upholstery as firmly as possible to ensure maximum protection – a recommended method is shown in these instructions.
6. Do not add to or modify this product in any way.
7. Never use this product if it has been in an accident, or if it has become badly worn. Periodically inspect the harness for wear, paying particular attention to attachment points, stitching and adjusting devices.
8. Do not leave a child in the seat unattended at any time.
9. Ensure that no part of the seat or seat belt is trapped in a door or a folding seat. If your car has a folding rear seat, ensure that it is correctly latched in its upright position.
10. Car interiors can become very hot when left standing in direct sunlight – it is therefore recommended that the child seat, when not in use, is covered by a towel. This prevents components, particularly those attached to the child seat, becoming hot and burning the child.
11. In the event of an emergency it is important that the child can be released quickly. This means that the buckle is not fully tamperproof and therefore your child should be persuaded never to play with the buckle.
12. Luggage and other heavy objects should be secured in the car. Loose objects are liable to cause injury in the event of an accident.
13. The child seat must not be used without the cover.
14. Never place your child seat on a table or work surface.
15. This seat can be used for children of 0–13kg in weight (approximately birth to 9 months of age) and is used in conjunction with a 3-point lap and diagonal safety belt in the rear-facing position only.
16. When the child seat is not in use, it is recommended that it is fastened into the car with a seat belt to avoid it being thrown about in the event of an accident.
17. In an emergency your child can be released quickly by pressing the red button on the harness buckle.
18. Store this child seat in a safe place when it is not being used. Avoid placing heavy objects on top of it.
19. If you travel with passengers using both the front and rear passenger seats, the lighter occupants should be in the rear and the heavier occupants in the front of the vehicle.
20. Do not allow your child seat to come into contact with corrosive substances e.g. battery acid.
21. The seat capsule cover must not be replaced with any other cover.

handle

To adjust the handle from one position to another, press the red adjust button on each side of the handle; rotate the handle forwards or backwards into the desired position until hearing a "click". The handle has 5 positions (as shown below).



Always ensure that the handle is locked in position and that the harness is correctly fitted and the buckle fastened before lifting your car seat.

harness

Before installing the bebe into the car, always check the harness straps are at the correct height for your child. The child's shoulders should always be below the slot for the harness.

adjusting the shoulder height:

The harness has 2 positions. The straps should go into the slots at, or the nearest slots above, the height of the child's shoulders. To adjust the harness, remove each strap by passing it through the slots from the front to the back of the seat; re-route the straps through the appropriate slots.



fastening the harness:

Slot the two plastic sections of the buckle connectors together. Insert the two connectors into the hole in the top of the buckle until they "click" into place. Always check that the harness is correctly locked by pulling above and below the buckle.

tightening the harness:

To tighten the harness, pull down on the adjustment strap until the harness is the correct tightness. (The harness should be adjusted as tightly as possible without causing discomfort to the child. A loose harness is dangerous and should be checked each time you use the seat).

slackening the harness:

The harness is loosened by pulling on both straps at the same time as pressing down on the harness adjuster button located on the shell underneath the "Press" word stitched on the cover.

unfastening the harness:


To release the harness, push the red button on the side of the harness buckle inwards. You can now lift your child from the seat; ensure that the buckle connectors do not catch on clothing.

fitting your car seat into the car

WARNING: This car seat can only be fitted into the passenger seat of a car with a lap and diagonal seat belt and no air bag.


THE TYPE OF APPROVED SEAT BELT YOU MUST HAVE

This car seat can only be installed rearward facing using a lap and diagonal seat belt in the front or rear passenger seat of the car.



Installation:

1. Place the capsule in a rearward facing position against the backrest of the car's seat (ensure the handle is in forward position).
2. Thread lap section of vehicle belt through the belt guides (labeled with dark blue arrow), across the foot end of the capsule and fasten the vehicle belt buckle.
3. Thread the shoulder section of the adult safety belt through the belt guides at the back of the bebe (labeled with light blue arrow).
4. Take out all the slack in the seat belt (both the lap and shoulder sections) and ensure there are no twists or kinks.



travel system compatibility

The bebe and bebe hs are compatible with all phil&teds inline™ buggies using the appropriate travel system (sold separately).

cuts & bruises

cleaning and caring for your bebe

The fabric cover can be easily removed for washing. Remove the harness by feeding the harness straps through from the front to the back of the seat, the crotch strap including the buckle should be removed; turn the metal slide underneath the shell on its side and feed it through the shell until the strap is free. Remove the cover and machine wash at 30°, line dry only.

The harness and plastic seat parts can be sponged with very mild detergent and warm water. Do not use chemical cleansers, bleach or corrosives on any part of the seat.

rights & remedies

*Consumers may have extra rights in some countries or states.

Our products are warranted against defects in materials and workmanship for one year from date of purchase. if the product has a manufacture fault we will repair it for free. if not practical to repair it, we will at our discretion, replace the part in question. if the product fails due to wear and tear, neglect or negligence, or is outside the warranty, we will happily repair it for a reasonable charge.*

who is covered? Original purchaser buying product from an authorized dealer. Proof of purchase is required.

what is covered? Workmanship or materials that are deemed faulty, providing car seat has at all times been used in normal conditions, in accordance with instructions, and been properly maintained.

what is not covered? Second hand product. modified product. poorly maintained product. normal wear, fading and fabric cuts. Improper use (by way of example): abnormal use; not following instructions; child left unattended; excessive load; transport damage i.e. airline or freight damage.

customer costs within warranty. Customer is responsible for any inwards freight charge to return product to manufacturer's representative for warranty and or service.

customer costs outside warranty. Where proof of purchase is not provided or product is outside of one year period. Manufacturer's representative reserves right to charge service fee and/or charge for parts replaced / repaired. a return freight charge may apply.

exclusions. Any consequential loss or damage to any person or property directly or indirectly as a result of using product.

who do I contact? Please discuss any warranty or service queries with your store of purchase. you will be required to show proof of purchase. they will inform you of the next step. products that are returned directly to the manufacturer by customers will NOT be eligible for warranty.

log on & relax

Please register your product purchase through our online warranty registration by visiting www.philandteds.com